

HorseGuard Crimper Tool & Lugs

What matters is the strength of the charger and the perfect electrical contacts.

Make the connection using the connectors that you will crimp onto the end of the high tension cables. By hooking the top part of the connector onto the Tensioner, you will create a perfect contact with no power leaks and no bad contact spots that would generate sparks and damage the tape.



Crimper #CRIMP59



Lugs #BP59GM



Crimper #CRIMP59



- 1/ Insert the end of the cable into the round cable stripper opening. Close the 2 sides of the crimper with the Vise-Grip pliers.
- 2/ Hit the crimper with a hammer against a wood block until both sides of the crimper meet. Pull off the cable insulation that has been cut.
- 3/ Fold the exposed wire strands over the cable insulation.



- 4/ Insert the terminal over them.
- 5/ Set the terminal into the hexagonal shape of the crimper
- 6/ Put the top and hit it hard with the hammer!

The terminal is now hexagonal, you have done it like a "pro"!

sandrine@horseguardfencing.ca
1.800.817.6930 (TOLL FREE)
horseguardfencing.ca

