

Installation Instructions:
ESTABLISHING THE MENTAL BARRIER



1. Remove a short length of stainless steel wire from the tape to use as sewing thread.
2. Sew the tape on the part of a halter located under the neck of the horse. The seam joining the two ends must be outside to avoid injury.
3. Sew the 2 layers of the tape from edge to edge to ensure good conduction.

