

Installation Instructions:
GATE HANDLES #BP13A & #BP12A

To create a gate with tape, one handle per row of tape is required.

Handle #BP13A
(small space between hooks)

2 possible uses:

- With #BP37 Tensioner without cables or nuts
- With the small Tensioner # BP32 with or without connection cables



Handle #BP12A
(large space between hooks)

2 possible applications:

- With the Tensioner #BP37 + connection cables + nuts
- With Tensioner block #9bl (item discontinued)



Installation Instructions:
GATE HANDLES #BP13A & #BP12A

