

Installation Instructions: **CRIMPING CABLE WITH THE NEW CRIMPER TOOL**



1. Put the end of the cable into the hole marked "strip"



2. Hit once or twice with a hammer



3. Without opening the crimper, pull the cable to strip it



4. Bend the exposed wire back along the cable and insert into the connector



5. Insert the connector with cable into the CRIMP slot and close the tool on it.



6. Strike with a hammer several times until the two sides of the tool meet.



7. Release the tool and ...



8. ... you have a professionally crimped cable!

Installation Instructions:
CRIMPING CABLE WITH THE NEW CRIMPER TOOL

OTHER USES OF THE NEW CRIMPER TOOL

